COORECTOR TEACH ME TO FLY! DUCK START GUIDE DUCK START GUIDE DUCK START GUIDE DUCK START GUIDE DUCK START GUIDE			
	EYE MOODS		
FLASHING RED	MEANS Low battery	ACTION Place me in my nest	
WHITE	Ready to play	Play with me	
YELLOW	I am hungry	Feed me my berry food	
BLUE	l am cold	Hold my forehead	
RED	I am sad	Pet my head	
GREEN	l am gassy	Pick me up and pat my back	
	I am dizzy	Pet my forehead to make me feel better	
PURPLE	l am singing	Move me side to side to get me to sing	
PINK	l love you	Pet my head	
RAINBOW	I AM READY TO FLY	Put me in my nest and watch me fly	



FLIGHT TIPS

Make sure I'm fully charged

 Use me indoors only
 Unplug my nest and place it on a flat surface
 Make sure I have space to fly by placing me away from walls and giving me overhead space

